

---

Access the following options through the *Function Keys*. Within a given menu, press the [YES] key to confirm an entry or the [NO] key to move backward through the menu.

## **BASIC PROGRAMMING**

---

Set Up Matrix: [OPTIONS]>SCREEN>MATRIX

Set Up Graph: [OPTIONS]>SCREEN>GRAPH

Change Displayed Data: [SELECT]>PAGE>MODE>PLACE>UNITS

Scroll Through Pages: [SELECT]>PAGE>UNITS

Tag Inputs: [SETTINGS]>SYSTEM>CONFIG>TAG

Adjust Contrast: [OPTIONS]>SCREEN>CONTRAST

Set Clock/Calendar: [SETTINGS]>SERVICE>CLOCK

## **ADVANCED PROGRAMMING**

---

Set Up Recorders: [SETTINGS]>OUTPUTS>RECORDER

Set Up Alarms: [SETTINGS]>OUTPUTS>ALARMS

Set Up AutoCal Interval: [SETTINGS]>SERVICE>REFS>INTERVAL

Entering Constants: [OPTIONS]>USER>PAGE

Entering User Functions: [OPTIONS]>USER>PAGE

Entering User Tables: [OPTIONS]>USER>PAGE

Computer Enhanced Response: [OPTIONS]>USER>PAGE

Set Up Data Logger: [OPTIONS]>LOGGER

Set Up RS232 Communications Port: [SETTINGS]>OUTPUTS>PORT

Set Up Error Processing: [SETTINGS]>SYSTEM>CONFIG>ERRORS

## **TESTING**

---

Test Alarms: [SETTINGS]>OUTPUTS>ALARMS>TEST

Test Recorders: [SETTINGS]>OUTPUTS>RECORDER>TEST

Trim Recorders: [SETTINGS]>OUTPUTS>RECORDER>TEST>TRIM

## **SETUP**

---

Configure Probes: [SETTINGS]>SYSTEM>CONFIG

Enter Calibration Data: [SETTINGS]>SYSTEM>CALIB>PROBE

Enter Reference Values: [SETTINGS]>SERVICE>REFS



## PROGRAM MENU OPTIONS

### Main Menu Options

