

Series 20 Pilot

{loadposition mooney_registration}

{youtube}PHiOruvPJMU{/youtube}

Series 20 Pilot: The Mooney series 20 pilot operates as the brain of Mooney and Flexflo regulators. It is a pressure control regulator designed to be used as a control pilot. It can be used in gas and liquids, and the same pilot can be configured for use in pressure reducing, or backpressure modes. The series 20 pilot has a large pressure range covered by six springs that are easily changed if needed, and it can be almost completely re-build in the field by replacing a small universal cartridge.

[DOWNLOAD](#)

(.MOV)

[DOWNLOAD](#)

(.WMV)